



English

Installation, Operation and Maintenance Instructions

Sun-Ray SRX

Solar Water Pumping Systems

Contents

| | |
|---------------------------------------|-----------|
| Warranty | 4 |
| Warranty Statement | 4 |
| Introduction | 5 |
| Intended Use | 5 |
| System Overview | 5 |
| Warnings | 5 |
| Solar Motor Controller (SMC) | 6 |
| Brushless DC Motor | 7 |
| SunRay SRX Pump | 7 |
| Optional Level Probe/ Float | 7 |
| Specifications | 8 |
| Motor Specifications | 8 |
| Solar Motor Controller Specifications | 9 |
| Cable Specifications | 11 |
| Pump Specifications | 12 |
| Installation | 15 |
| Block Diagram | 15 |
| Installation Procedure | 16 |
| Commissioning | 19 |
| Operation | 20 |
| Operation of the SMC | 21 |
| Float Switch input | 21 |
| Pump Speed Control | 21 |
| Sun-Sub Totaliser Operation | 21 |
| Pressure Cut off system. | 22 |
| Solar Display Unit | 23 |
| Trouble Shooting Guide | 24 |
| Maintenance | 25 |
| Spare Parts | 28 |

Warranty

Warranty Statement

1. The Sun-Ray Solar SRX Water Pumping System manufactured by Mono Pumps are covered by warranty for a period not exceeding twenty-four months from purchase.
2. Mono Pumps will make good by repair, or at their option, the replacement of faulty parts under warranty, providing always that:
 - (a) The equipment was correctly installed and properly used in accordance with Mono Installations and Operating instruction and accepted codes of good engineering practice.
 - (b) The claim for goods under warranty arises solely from faulty design, material or workmanship.
 - (c) The repair is carried out in the Mono Pumps factory or by an authorised agent or distributor appointed by Mono Pumps.
 - (d) All freight costs to and from the factory or repair agent are to be paid by the purchaser.
3. In the case of equipment or components which are not of Mono Pumps manufacture, but supplied by them, the warranty is limited to that extended by the suppliers or manufacturers of such equipment.
4. Mono Pumps warranty does not cover any of the following:
 - (a) Claims for third party liability of damage caused by failure of any of the company's products.
 - (b) Damage caused by abnormal operating conditions, war, violence, storm cataclysm or any other force.
 - (c) Damage caused by the equipment being used for an application for which it is not recommended.
 - (d) Damage caused by sand or abrasive materials, corrosion due to salt water or electrolytic action.
 - (e) Damage to the SMC if the SMC has been opened by removal of the back plate before being returned to Mono.
 - (f) Damage to the motor if the motor is found to have been disassembled before being returned to Mono Pumps.

(g) Damage caused by running the pump dry.

5. The decision of Mono Pumps in relation to any claims or disputes over warranty is final.
6. The warranty is in lieu of all other warranties and conditions expressed or implied, written or oral, statutory or otherwise, which are hereby negated and excluded.
7. This express warranty does not exclude any conditions or warranty implied by the Trade Practices Act 1974 or separate State laws and in addition to any other right, that the original purchasers or any subsequent purchaser may have at law.

In case of claim please contact your Authorised Mono Pumps dealer or contact Mono Pumps (Australia) Pty Ltd.

Introduction

Intended Use

The Sun-Ray SRX Solar Water Pumping system is designed for pumping potable water using solar power. Do not use the system for any other purpose.

The protection provided by the equipment may be impaired if the equipment is used in any other manner than designed.

System Overview

Mono Pumps Sun-Ray Solar Water Pumping Systems are comprised of four main parts:

- 1 Either a stationary or tracking solar array.
- 2 Solar Motor Controller (SMC).
- 3 Brushless DC Motor (BLDC) with electrical cable and plugs
- 4 CP Pump (Wet End) which is direct coupled to the BLDC motor.

Additional items such as Floats, Termination Kits, Water Level Controllers (WLC's), Float Switches, etc. may also be supplied with the system. The pump suction, discharge piping and all equipment, foundations and ancillary structures, unless otherwise requested is the responsibility of the installer. The installation, operation and maintenance of the Solar Array are not covered in this manual. Please refer to the Solar Arrays manual for information on this part of the solar water pumping system.

Warnings



Solar arrays can deliver voltage levels up to 160V DC. Always unplug the SMC from the array before working on any electrical wiring on the SMC or Motor Cables. In the event that alterations are required to the array itself, it is essential to cover the front of the array with a blanket or other suitable material to completely stop electrical generation.



The output voltage from the SMC to the Motor is 180V DC. Always unplug the SMC from the array before working on any electrical wiring on the SMC or Motor Cables.



All electrical connections in the solar water pumping system are made via plug and socket. The solar array must be fitted with a switched socket to accept the plug from the SMC and to ensure that the system can be completely isolated from the power source when required.



Motors can get hot during operation. Ensure all motors protected from direct sun, and have good ventilation.

Ensure absent of any combustable items surrounding motor.

Introduction

Solar Motor Controller (SMC)



Do not handle electrical connections when wet. Electric shock can occur.

The SMC comprises a solar maximum power point tracker and brushless DC motor control electronics combined in the one enclosure.



The MPPT converts and adjusts the voltage on the solar array to maximise power generation and increases or reduces this voltage to suit the demands of the motor controller.

The motor controller is an electronic commutator replacing the brushes in conventional DC motors. The motor controller senses back EMF voltages from the motor to determine the rotor position. This information is fed into a micro computer to calculate the energising sequence for the motor phases.

Features include:

- Input power ranges from 150 Watts to 2400 Watts from solar modules (refer to specifications for voltage, current and power limits for each SMC model.)

- Microprocessor controlled maximum power point tracking continuously changes the array voltage and monitors the input power level thus following changes in the maximum power point of the array. This technology extracts the maximum available power from the solar modules.
- Remote On/Off control via float, pressure switch or water level control via probes placed in the bore hole.
- Electronic pressure cutoff system.
- Easily accessible On/Off switch.
- Interface to an optional Hand Held Display Unit
- Variable motor speed control via front panel or the optional Hand Held Display Unit.
- Thermal overload protection
- Input current overload protection detects if too many solar modules are connected to the SMC or if high currents are supplied from a battery source.
- Output current overload protection stops the system if the discharge pressure from the pump is too high.
- If the power output from the array is too low to start the pump, the system goes into “sleep” mode before attempting to restart the pump. This reduces load on the circuits and heating of DC motors.
- Low motor speed cut off to reduce pump and motor wear.
- Float Switch Input Protection prevents damage if accessory devices connected to the float switch socket are wired incorrectly.
- Status lights to tell the operator what the system is doing.

Introduction

Brushless DC Motor

The Mono Pumps Sun-Ray SRX System uses a high efficiency, brushless, sensorless, permanent magnet, DC, motor designed for coupling to the Mono Pumps Sun-Ray pump.

The motor has a permanent magnet rotor and supported by low lose bearings with all the drive electronics housed separately in the SMC. No sensor is required to determine rotor position within the motor.

Sun-Ray Pump Wet End

The progressing cavity pump has been designed specifically for use on the Sun-Ray SRX system. The wet end is either a CP25, CP800 or CP1600 type pump.

The high operating efficiency of the motor pump and SMC ensures that the maximum amount of water can be pumped over the whole day and during cloudy conditions.

Optional Level Probe or float



Part # SUN S0889 or SUN S0648

Mono can supply a separate level probe or float switch. This probe device plugs into the Float Switch outlet on the SMC.

The float switch/ level probe will protect the pump from dry running if the source water level drops to the level of the inlet to the pipework. The dropped float (open circuit) needs to be set above the height of the opening of the suction pipe.



Dry running of the pump will damage the rubber stator in the pump. Damage resulting from dry running is not covered by the system warranty.

Specifications

Specifications

Motor Specifications

Size Range

| | 700W | 1400W |
|-------------------------------------|-------------|--------------|
| Output Power Rating | 0.7Nm | 1.5Nm |
| Nominal Torque Rating | 1800rpm | 1800rpm |
| Nominal Speed at rated power | Yes via SMC | Yes via SMC |
| Variable Speed Control | | |
| Efficiency at Nominal Torque Rating | 85 % | 85 % |

Electrical Characteristics

| | | |
|-----------------------------------|------------|------------|
| Maximum Operating Voltage (motor) | 180V | 180V |
| Input Voltage Range | 0-180V DC | 0-180V DC |
| Operating Frequency Range | 0 - 100 Hz | 0 - 100 Hz |
| Maximum Current | 3 amps | 5 amps |

Materials

| | <i>All models</i> |
|------------------------------------|-------------------------------|
| Motor Cable | 4 Core 1.5mm ² |
| Casing, end caps, rotor can, shaft | Anodized Aluminium |
| Studs, screws, nuts and washers | 316 stainless steel |
| Magnets | NdFeBr (Neodymium Iron Boron) |

Water Quality

| | |
|---------------------------|--|
| Maximum Water Temperature | 35 deg C, also see Pump Specifications |
| pH range | 8.5 to 6.0 |
| Hardness Range | 2000 Mg/L |
| Salt Concentration | 500 ppm |

Specifications

Solar Motor Controller Specifications

Electrical

Solar Array Input

Series 2000 SMC

Voltage : 30 to 165 VDC
Current : 0 to 5 A
Solar Array: 700W Max.

Series 3000 SMC

Voltage : 30 to 165 VDC
Current : 0 to 15 A
Power: 1500W Max.
Solar Array: 3000W Max.

Motor output

Series 2000 SMC

Voltage : 0 to 180V
3 Phase switched DC
Frequency: 0 to 100 Hz
Current : 0 to 4 A

Series 3000 SMC

Voltage : 0 to 180V
3 Phase switched DC
Frequency: 0 to 100 Hz
Current : 0 to 9 A

Float Switch connector

Switch input (pin 3,4)

Operation Normally closed
Shutdown on open contact

Current: 3mA (closed circuit)

Voltage: 15V (open circuit)

Auxiliary Supply (pin 1,2)

Voltage: 15VDC Nominal

Current: 50mA max (10V)

Com Connector

RS232
9600 baud
rts/cts

Environmental

Storage Temperature: -10 to 60C

Operating Temperature: -10 to 50C

IP Rating: Type 3, Water and dust tight.

Humidity: 95% Max.

Dimensions & Weight

Dimensions (Carton)

390 x 275 x 290mm

Weight (in carton) 6.5Kg

Refer following page for further dimensions.

Lightning Protection


In a solar water pumping system it is necessary to avoid having two earth points. (e.g. The motor itself and the earth rod attached to the solar array frame.) Mono recommends tying the pump safety wire to earth and bonding across to the earth stake with a 1.0"-2.0" galvanized earth strap.

The most vulnerable point is at the motor cable entry to the electronics where it is possible to receive an extreme earth potential rise after a lightning strike nearby.


Metal Oxide Varistors are fitted on the array input and Transorbs on the Motor output.

Specifications

Series 3000 SMC Dimensions



Series 2000 SMC Dimensions



Specifications

Cable Specification

Motor

| | | |
|------------|------------------|--------------------------------|
| Motor Plug | 180V, 9A | |
| Cable | Double Insulated | |
| | 250V | |
| | 4 Core | 1.5mm ² for lengths |

Array

| | | |
|------------|------------------|------------------|
| Array Plug | 165V, 15A | |
| Cable | Double Insulated | |
| | 1000V | |
| | Single Core | 4mm ² |

Float Switch

| | | |
|-------------------|---------------------------|---------------------------------|
| Float Switch Plug | 15V, 50mA | |
| Cable | Double Insulated | |
| | 250V | |
| | 4 Core 0.5mm ² | Systems with two float switches |
| | 2 core 0.5mm ² | System with one float switch |

Com Port

| | | |
|---------------|------------------|--|
| Com Port Plug | 15V, 50mA | |
| Cable | Double Insulated | |
| | 250V | |
| | 6 Core | |

Specifications

| Size Range Model Numbers | CP25 | CP800 | CP1600 |
|---------------------------------|------|-------|--------|
| Maximum Speed [rpm] | 1800 | 1800 | 1800 |
| Flow at Maximum Speed [lpm] | 28 | 68 | 130 |
| Max Discharge Pressure [kPa]* | 500 | 350 | 350 |
| Max Suction Head (kPa) | 6m | 6m | 3m |
| Max Differential Pressure (kPa) | 500 | 350 | 350 |
| Total Pump Weight (inc Motor) | 10Kg | 15Kg | 18.5Kg |


* At Flooded Suction

Materials

All models

| | |
|--------------------------------|--|
| Pump Housing | Acetyl Co-Polymer |
| Stator | Nitrile Rubber |
| Coupling/Motor Shaft | 316 stainless steel |
| Rotor | 316 stainless steel |
| Fasteners | 316 stainless steel |
| Non Return Valve (if supplied) | Bronze with Nitrile seat and anti-rotating pin |
| O rings | Nitrile |
| Mechanical seal | Carbon / Ceramic |




| | |
|----------------|--------|
| Float Diameter | 1200mm |
| Float Height | 670mm |
| Float Weight | 27kg |



Specifications




CP25 Standard Build p/n: SUN 700CP25S

5 metres 4 core 1.5mm² cable




CP25 High Pressure Build p/n: SUN 700CP25H

5metres 4 core 1.5mm² Cable




Specifications


CP800 High Pressure Build p/n: SUN 700CP800H





CP1600 High Pressure Build p/n: SUN 1400CP1600H



Installation




Installation



Floating Pontoon: (where applicable)

All floating pump units are fully wired in the factory and can be simply placed in a dam or creek after connecting the suction and discharge pipe work. Ensure that the pontoon is loosely located in position by ropes or guy wires connected to the tether points supplied on the pontoon. The other end of the guy wires should be connected to a fixed anchor on the bank such as a star picket. Ensure that the ropes are loose enough to enable the unit to rise and fall with changing water levels.

Discharge pipe work is not supplied with the systems. When selecting pipe work take into account the friction loss that will occur if smaller bore pipes are used, such friction losses can dramatically affect daily flow of the system.



The power cable should be attached to the discharge pipe work with cable ties, and then fixed to the floats supplied with cable ties, as shown below.



If the discharge pipe work is not floated on the surface, there is a likelihood that the pontoon may roll over due to the weight of the water in the pipe work.

Installation

Installation Procedure

General

The following describes the installation of the Pump and SMC. Refer to the separate Solar Arrays manual for information on installing the Solar Array.

The Warranty does not cover damage due to running the pump dry. If there is a possibility that the pump suction will drop below the water level, Mono Pumps recommend that a Level float is fitted to the system.

It is recommended that all pumps be protected from direct sunlight. This can be done using a small sheet metal cover.

All pumps to be mounted on a secure base such as a concrete pad. This will ensure all pipework is fully supported to limit the forces on pipe fittings.

On long suction lines, it is suggested that the following steps be followed:

- a. A foot valve be added to the end of the suction pipe to ensure the suction pipe does not empty when the pump is off
- b. Prior to commissioning the pump the suction line is fully water changed
- c. A 'goose neck' pipe arrangement is applied on the suction connection to the pump. This is done to ensure the pump holds more water.
- d. The end of the suction pipe is clear from obstruction (i.e the bottom of the dam) and also clear of water surface, so not to suck in any air.
- e. For long suction lines, it is recommended that the suction pipe be buried. Unburied pipe will heat the water in the suction line which can effect pump performance and life.

It is recommended that a low lose check valve be added to the discharge line of every pump, as close to the pump connection as possible. This will ensure no water leaks back through the pump when not running, ensuring the most efficient operation. This will also ensure the pump does not turbine, which may effect the system life.



Motor Plug



The output voltage from the SMC to the Motor is 180V DC. Always unplug the SMC from the array before working on any electrical wiring on the SMC or Motor Cables.

SMC End

If the motor plug was removed from the cable during the installation process it is important that the wires are reconnected correctly to ensure that the pump runs in the correct direction.



Installation

Mounting the Solar Motor Controller (SMC)

Attach the SMC to the bracket on the array frame using stainless steel M8 bolts, nuts and washers.

Earthing the Solar Array

The post or one of the support legs of the solar array must be earthed to provide lightning protection for the system and to prevent the array structure from becoming “live” in the case of a fault with the array or SMC.



Refer to the Commissioning section on the following page for instructions on connecting the electrical wiring and starting the system for the first time.

Wiring the Float Switch Plug



Warning: Ensure that all plugs are fitted correctly to the SMC. Failure to fit the plugs correctly will allow water to enter into the SMC leading to failure. This is not covered by warranty.

The Float Switch is fitted with a blanking plug as standard. The assembly of the float switch plug and wiring of the blanking plug are shown below.



The SMC will only operate when pins 3 and 4 of the float switch are connected. The blanking plug contains a link wire

to connect these two pins. External switches can be wired into the float switch to remotely start and stop the pump.

Float Switch Pin Connections

Pins 1 is the positive output of 15 volt DC power supply used to power the optional water level controller.

Pin 2 is the negative output of the 15 volt DC power supply

Pin 3 is the positive connection to the float switch.

Pin 4 is the negative connection to the float switch.

Note: The 15 Volt power supply is not suitable for charging lead acid batteries.

Commissioning

(Starting the system for the first time)



Warning: Incorrectly connecting the positive and negative wires between array and the SMC will result in damage to the electronics inside the SMC.

Electrical Connections

The Solar Motor controllers utilise 2 “MC” style leads to connect the SMC to the Solar array.

Switch the SMC off using the On/Off Switch on the front of the SMC.

Plug the Motor Plug into the motor socket on the SMC. Ensure that the motor cable is adequately protected from damage by animals or livestock. The cable should be attached to the array post or support frame with electrical ties to prevent the motor plug from being accidentally pulled out of the SMC.



Solar arrays can deliver voltage levels up to 160V DC. Always unplug the SMC from the array before working on any electrical wiring on the SMC or Motor Cables. In the event that alterations are required to the array itself, it is essential to cover the front of the array with a blanket or other suitable material to completely stop electrical generation.



Warning: Removing the motor plug from the SMC or shorting the wires together when the SMC is operation, could result in damage to the electronics in the SMC.



Warning: Ensure that all plugs are fitted correctly to the SMC. Failure to fit the plugs correctly will allow water to enter into the SMC leading to failure. This is not covered by warranty.



Switch the isolation switch on the array to the off position (if fitted).

Connect the 2 metre MC cables between the SMC and solar array switch located on the back of the solar array.

Fit the blank float switch plug into the float switch socket on the front of the SMC. The SMC will not operate without either the blank plug or a correctly wired accessory plug fitted to the SMC. For the initial system test, it is recommended to use the jumper plug. Other accessories such as the Water Level probe can be installed if necessary after the operation of the SMC and motor is confirmed.

Starting the system

When starting the system for the first time it is recommended that the discharge pipe is not connected to the pump. Ensure that the suction line is also within the allowable suction height. If the suction line is long it is recommended that a foot valve be installed on the line and also a goose neck arrangement be added to the pump.

Fill the suction of pump in all cases and for long suction runs fill the suction line.



Turn the array isolation switch to the on position (if fitted).

The Solar Power Status Light should light up indicating that power is available from the array.

Switch the SMC On using the On/Off switch on the SMC. The Motor Start Status Light should flash indicating that the pump is starting. When the pump has started the Motor Start Status Light will turn off and the Max Speed / Motor Run Status Light will flash or turn on continuously.

Operation

Operation of the SMC



Status Lights

The SMC features five multifunction system status lights (LED's). The first function of each light is indicated by continuous illumination of the LED. A flashing LED indicates the second function. The functions of the LED's are as follows:

SMC's Diagnostic Indicators

Solar Power / Low Power

Lights up when solar power is available.

The indicator flashes when the unit is turned off via the On/Off switch or via the Com Port.

The indicator turns off if insufficient power is available to the SMC.

Max Speed / Motor Run

Lights up fully when the motor is running at maximum speed

Flashes proportional to the speed of the motor at lower speeds

Float Indicator

The indicator lights up when the float switch input is open

It flashes when the SMC is in the float switch delay mode

Pressure

The pressure indicator lights up when the pump pressure exceeds the preset limit

The indicator flashes when the SMC is in the pressure delay mode

Overload / Input/Temp

Lights up if the motor is overloaded

Flashes slow if the input current reaches the maximum value

Flashes fast if the SMC over heats

Operation

Float Switch input

The SMC's Float switch input has been designed to operate on float switch (SUN S0648), single level probe (SUN S0889) or tank float switch. The SMC will attempt to start the motor if there is a closed electrical connection across the float switch input (Pins 3,4). If the circuit is opened via the bore/float switch the motor will be stopped and the Float Indicator will illuminate. Once the bore/float switch has re-closed, a 15 minute time delay will become active, continuing to stop the motor. The Float indicator will flash as the timer is counting down. When 15 minutes has elapsed the SMC will attempt to start the Motor and the indicator will turn off.

Pushing the On/Off button will cancel the time delay on the float switch input.

The float switch input can be configured to run the optional Mono tank and bore level controller (SUN 0415).

Pump Speed Control

The pump speed feature can be used to limit the maximum speed of pump, therefore reducing the peak flow of the pump. This is useful when the peak flow needs to be reduced as in a low yielding bore.

These SMC's have 2 methods of reducing the maximum motor speed, firstly by pushing the front panel speed switch or by using the Solar Display unit.

a/ Front Panel Speed Button

Pushing the Speed button will increase the maximum speed by 20% each push. The initial push will illuminate the number of indicators corresponding to the current maximum speed setting, if the switch is pushed again the maximum speed will be increased by 20% (36V). Once the absolute maximum setting of 100% (180V) has been attained the next push will revert back to the 20% setting.

b/ Solar Display Unit (SDU)

To reduce the maximum pump speed using the SDU, plug the SDU into the SMC and follow these steps:

- i/ Press enter (#) on the SDU to clear any previous operation.
- ii/ Press * 6 # , the display should read "Max Motor Volt ?"
- iii/ Enter the desired maximum motor voltage between 36 and 180V, for 100V press 100# , the display should now read "Max MotorV=100V".

Note: The SDU setting will override the maximum available Speed button setting, therefore the front panel switch can only increment the speed up to the SDU setting.

SMC Totaliser Operation

The SMC controllers have an inbuilt totaliser function. This function counts every revolution the pump has done since installation. This reading can be used as a method for totalising the flow from the installation.

1/ To recall number of Pump Revolutions from the SMC enter *8# on the Solar display unit for 150, 300, 600, 1200W SMCs (software V1.3 or greater) enter *7# on the Solar display unit.

2/ Pump conversion factors

| | | |
|--------|----------------------|------|
| CP25 | (pressure below 20m) | 12 |
| CP25 | (pressure above 20m) | 13.5 |
| CP800 | (pressure below 20m) | 27 |
| CP800 | (pressure above 20m) | 33 |
| CP1600 | (pressure below 20m) | 56 |
| CP1600 | (pressure above 20m) | 67 |

3/ To calculate litres pumped

Total Litres = Revolutions/Pump Factor
e.g. 1340000 Revs CP25 Pump at 40m
 $1340000/13.5 = 99,259$ litres

Operation

Pressure Cut off system.

This system has been designed for use as a method for controlling the filling of a remote storage tank. A float valve is fitted in the remote tank, once the tank is full the valve closes, this causes the pressure to build up in the system tripping the Pressure cutoff system. The pressure cutoff system electronically monitors the Pumps operating pressure, if the pump pressure rises above the preset limit the pump will automatically stop for 30 minutes, after 30 minutes has elapsed the SMC will then attempt to restart the pump. The pressure indicator on the front panel shows whether the system has been shut down via the pressure cutoff system. The indicator will illuminate when the pressure limit has been reached, it will flash when the unit is counting down for 30 minutes.

SETUP (The Mono Pumps Solar Display Unit "SDU" is required for this operation)

- 1/ Program the Pump model (Normally programmed before the unit is shipped from Mono).

If you want to check which pump model is selected, press * 7 # on the SDU keypad, the SDU will now ask for a Pump Model. Press 0 # ,the SDU will now display the current pump selection.

To change the Pump model ,using the SDU press * 7 #, the SDU will now ask for a Pump Model. Enter the 3 number pump code corresponding to the Pump model fitted to the motor then push the # key.

Example. CP025=025#, CP800=800#, CP1600=160#

- 2/ Measure Pump Pressure.

Start the pump, when the pump is running at its maximum speed and the pipes and tanks are full, measure the pressure using the SDU. Using the SDU press * 5 # ,this will give a dynamic pressure reading. Once you have determined the maximum operating pressure add a minimum of 20 metres (to allow for any variances) to the value, this will give you the Pressure cut off point.

Example. SDU maximum reading 25M
Pressure Cutoff Point = 45M

Note: A pressure gauge fitted to the pump outlet will be helpful in determining the maximum pressure of the system, but importantly the SDU pressure displayed is measured at the Pump not the top of the bore. Allowance must be made for this when programming the cutoff point.

- 3/ Set Pressure Cutoff Point

Using the SDU press * 2 #, the SDU will now ask for a pump pressure. Enter the require pressure limit then press the # key. e.g. 65 Metres=65# , 35 Metres=35# ect.

If you want to check what the trip pressure is set to, press * 2 #, the SDU will now ask for a pump pressure. Press 0 # the SDU will now display the current pressure trip setting.


- 4/ Test the system.

Close the float valve fitted in the tank to simulate a full tank. This should make the pressure in the system increase over the trip point, the pressure indicator should turn on and the pump shutdown. The pressure Indicator will flash to indicate the system is in delay mode. If a SDU is connected to the SMC it will display the time to restart in Minutes.

Pushing the On/Off button will cancel the time delay once the pressure cutoff system in active.

Operation

Solar Display Unit



The Solar Display Unit is an optional accessory that allows the operator to extract data from the SMC and change software settings within the SMC. The unit has a two line display. The first line displays information on the current operating mode of the SMC. E.g. Motor Starting, Input current overload, maximum motor speed etc. The second line of the display shows information depending on the currently selected function. The primary functions are listed on the keypad on the front of the unit. E.g. To see the array voltage press key 1 then the Enter key. The second line will now display the array voltage. The voltage will be updated continuously until a new function is selected.

The display unit is powered from the SMC but also contains a 9 volt battery. If the SMC is running the display unit takes power from the SMC (i.e. it will operate even if the internal battery is flat.) If the SMC is not connected to an array or the array is not generating any power, the display unit will run of the internal battery. The display unit will also power up the microprocessor on the Power Master so that settings can be changed in the SMC without the SMC being connected to a solar system. When the SMC is running of the Solar Display Unit the Solar Power / Low Power light on the SMC will flash indicating that there is insufficient power to operate the pump.

A list of the primary functions is shown below.

Primary Functions

- 0 Motor On/Off (turns the system on or off)
- 1 Array Volts
- 2 Array Amps
- 3 Array Maximum Power Point (Normally auto but if the voltage has been fixed the set voltage will be displayed.)
- 4 Motor Volts
- 5 Motor Amps
- 6 Max Motor Volts (The default is 180 volts but by setting a lower maximum motor voltage the maximum speed of the pump can be controlled. This is useful in applications where the yield of the bore is low.)
- 7 Motor RPM
- 8 Serial Number and Date of Manufacture of the SMC
- 9 Unit ID of the Solar Display Unit

Second Functions

There are additional functions that can be accessed by pressing the * key followed by the number key and enter then the value and enter. E.g. To set a new maximum motor voltage of 90 volts press * 6 enter 9 0 enter.

- 1 Array Power
- 2 Set Pressure Limit (0 reads current setting)
- 3 Set Array MPP (Used to turn off the maximum power point tracking and set the voltage to a fixed value. 0 returns to auto mode.)
- 4 Motor Power
- 5 Pump Pressure
- 6 Set Maximum Motor Voltage
- 7 Set Pump Model (0 reads current setting)
- 8 Revolution Counter
- 9 Restores the SMC to the factory default settings

Operation

Trouble Shooting Guide

| Status Light | State | Possible Problem | Solution |
|---------------------------|--------------------------|---|---|
| Solar Power | Off | Loose array connection | Test array & rectify problem |
| | | Faulty array | Test array & rectify problem |
| | | Faulty SMC | Return to Mono for assessment |
| | | Not enough solar power | Check array position or wait for more sun light |
| | Flashing | On/Off switch set to off | Push On/Off switch |
| Remote control set to off | | Push On/Off switch | |
| Motor Speed | On but no flow from pump | Motor disconnected from pump | Reconnect motor to pump / check direction of rotation |
| | | Broken Shaft /Coupling | Replace Flexishaft / Coupling |
| | Flashing / slow | Array partially faulty | Test array & rectify problem |
| | | Pump load increased | Check for obstruction in the pump non-return valve or increased head due to pipe blockage |
| | Off | System is waiting for enough power | Need more solar power |
| | | Stuck pump | Clear or prime pump |
| | | Faulty motor | Return to Mono for assessment |
| Off/Float | On | Pins 3,4 of float switch connector open circuit | Check link in dummy plug |
| | | Float / pressure switch open circuit | Check operation of float / pressure switch |
| | Flashing | In delay mode | Push On/Off switch twice |
| Pressure | On | Pump Overpressured | Release Pressure in system |
| | Flashing | In delay mode | Push On/Off switch twice |
| Overload | On | Motor overload | Check system head |
| | | Pump over pressured | Remove source of flow obstruction |
| | Flashing | Wrong array configuration | Test array & rectify problem |
| | Flashing/fast | SMC too hot | Check SMC location for ventilation |

Maintenance

Solar Motor Controller (SMC)

There are no user serviceable parts inside the SMC. If the SMC is not functioning correctly it must be returned to Mono Pumps for service.



Any disassembly of the SMC by unauthorized personnel will invalidate all warranty. The back plate/heat sink must not be removed under any circumstances.

Motor

There are no user serviceable parts inside the Motor. If the Motor is not functioning correctly it must be returned to Mono Pumps for service.



The Warranty on the motor is void if it is disassembled. All repairs and maintenance must be carried out at the Mono Pumps factory.

Sun-Ray Pump Wet End

This process is outlined on the next few pages via exploded views.



WARNING: Do not use grease, soap, hand cream, etc. to lubricate the Stator. These products will damage the natural rubber stator and result in seizure of the pump. When assembling the rotor into the stator it is only necessary to wet the components in water.


Final Assembly

Wet the rotor and stator with water and slide the stator assembly over the rotor assembly. Some resistance will be felt as the rotor is pushed into the stator.


Maintenance

Disassembly CP800 and CP1600 SRX


Below shows a general exploded view of the unit



To disassemble the rotor and flexible coupling from the motor, remove the rubber grommet from the back of the motor, use a 10mm Allen key in the back of the motor and turn rotor using a spanner on the flats in the direction shown.



If the rotor unscrews on the coupling, to remove the coupling there are flats on the end which can be held using vice grips can turning in the same direction as above. If not enough torque can be applied using this method, use a 5 mm pin into the shaft hole through the drain hole (as shown below). Then turn the allen key in the direction as shown above.




Notes

For reassembly use nickel anti-seize on the flexible coupling to motor shaft connection.


Maintenance

Disassembly CP25 SRX


Below shows a general exploded view of the unit



To disassemble the rotor and flexible coupling from the motor, remove the rubber grommet from the back of the motor, use a 10mm Allen key in the back of the motor and turn rotor using a spanner on the flats in the direction shown.



Maintenance




SUNRAY SRX CP25 HIGH PRESSURE

P/N: SUN 700CP25H

| ITEM | DESCRIPTION | PUMP NUMBER | QUANTITY |
|-----------|----------------------|------------------|----------|
| 1 | Motor Surface BLDC | SUN-BLDC700CP25 | 1 |
| 2 | Pump Body | AC CP11 0100 | 1 |
| 3 | Mechanical Seal kit | MPK-SK011 | 1 |
| 4 | Pump Rotor | SF CP25 2520 | 1 |
| 5 | Pump Stator | RR CP25 2210 | 1 |
| 6 | O Ring | Part of MPK-SK01 | 1 |
| 7 | Expansion Ring | SUN S0996 | 1 |
| 8 | End Cover | AC CP11 2400 | 1 |
| 9 | TAPER PLUG 1/4' BSPT | OO CP00 0430 | 1 |
| Not Shown | M8x40 S/S Stud | SUN M0254 | 4 |
| Not Shown | M8 Plain Washer S/S | W113051F | 20 |
| Not Shown | M8 Spring Washer S/S | W113251F | 12 |
| Not Shown | M8 Nut S/S | N113100F | 12 |
| Not Shown | Electrical Plug | SUN 23565-3 | 1 |

Spare Parts



SUN 700CP800H

SUN 1400CP1600H

| ITEM | DESCRIPTION | PUMP NUMBER | PUMP NUMBER | QUANTITY |
|-----------|-------------------------|----------------|-----------------|----------|
| 1 | Motor Surface BLDC | SUN-BLDC700W | SUN-BLDC1400W | 1 |
| 2 | Pump Body | AC CP1600 0100 | AC CP1600 0100 | 1 |
| 3 | Pump Foot | AL CP1600 6200 | AL CP1600 6200 | 1 |
| 4 | Mechanical Seal kit | OO CP800 1060 | OO CP800 1060 | 1 |
| 5 | Pump Rotor | SF SWP800 2500 | SF SWP1600 2500 | 1 |
| 6 | Pump Stator | RR CP800 2210 | RR CP1600 2210 | 1 |
| 7 | Flexible Coupling | SUN S0996 | SUN S0995 | 1 |
| 8 | Coupling Sleeve | SUN S0991 | SUN S0991 | 1 |
| 9 | Expansion Ring | SUN S0997 | SUN S0997 | 1 |
| 10 | Expansion Seal | SUN S0990 | SUN S0990 | 1 |
| 11 | End Cover | AC CP800 2400 | AC CP800 2400 | 1 |
| 12 | Hex 1/4" Plug | OO CP00 0430 | OO CP00 0430 | 1 |
| Not Shown | Electrical Plug | SUN 23565-3 | SUN 23565-3 | 1 |
| Not Shown | M8X40 316S/ST STUD | SUN M0254 | SUN M0254 | 2 |
| Not Shown | M8X50 316S/ST | SUN M0417 | SUN M0417 | 2 |
| Not Shown | M8 X 90 HEX HD BOLT S/S | K113381F | K113381F | 4 |
| Not Shown | M8 X 80 HEX HD BOLT S/S | K113361F | K113361F | 4 |
| Not Shown | M8 Nut S/S | N113100F | N113100F | 12 |
| Not Shown | M8 Washer | W113051F | W113051F | 20 |
| Not Shown | M8 Spring Washer | W113251F | W113251F | 12 |

This page left blank

This page left blank

Europe

Mono Pumps Ltd, Martin Street, Audenshaw
Manchester, M34 5JA, England
T. +44 (0)161 339 9000
E. info-mono@nov.com

NOV Mono, 56, rue du Pont
88300 Rebeuville, France
T. +33 (0)3 29 94 26 88
E. monofrance@nov.com

Africa

NOV Monoflo, No. 10 Dipka Road
Kaymore Industrial Area
Stikland, Bellville 7530
Cape Town, South Africa
T. +27 (0)21 941 2900
E. monofloafrica@nov.com

Americas

NOV Monoflo, 8708 W. Little York Rd, Suite 100
Houston, Texas 77040, USA
T. +1 281 854 0300
E. monoflo@nov.com

NOV Monoflo S.A., Ing Huergo 2239
(1842) Monte Grande
Pcia. de Buenos Aires, Argentina
T. +54 11 4290 9940/50
E. monoflo@nov.com

Australasia

Mono Pumps (Australia) Pty Ltd
75 Frankston Gardens Drive
Carrum Downs, Victoria 3201, Australia
T. 1800 333 138
E. ozsales@nov.com

Mono Pumps (New Zealand) Ltd
Fremlin Place, Avondale
Auckland 7, New Zealand
T. +64 (0)9 829 0333
E. info@mono-pumps.co.nz

Asia

Mono Pumps Ltd, Building 5, Madong Industrial Park
1250 Sicheng Road, Malu Town, Jiading District
Shanghai 201801, P.R. China
T. +86 (0)21 3990 4588
E. monoshanghai@nov.com

| | | | | |
|-----------------|----|----------------|----|----------------|
| Melbourne | T. | 03 9773 7777 | F. | 03 9773 7400 |
| Sydney | T. | 02 8536 0900 | F. | 02 9542 3649 |
| Brisbane | T. | 07 3350 4582 | F. | 07 3350 3750 |
| Adelaide | T. | 08 8447 8333 | F. | 08 8447 8373 |
| Perth | T. | 08 9303 0444 | F. | 08 9303 0400 |
| Darwin | T. | 08 8931 3300 | F. | 08 8931 3200 |
| Kalgoorlie | T. | 08 9022 4880 | F. | 08 9022 3660 |
| Christchurch NZ | T. | +64 3 341 8379 | F. | +64 3 341 8486 |

www.monopumps.com.au



© Mono Pumps Limited March 2013 Literature reference: MPA582/7

Published information other than that marked CERTIFIED does not extend any warranty or representation, expressed or implied, regarding these products. Any such warranties or other terms and conditions of sales and products shall be in accordance with Mono Pumps Limited standard terms and conditions of sale, available on request.

Mono® is a registered trademark of Mono Pumps Ltd.

Registered in England No 300721

NOV Mono®

One Company, Unlimited Solutions